

Care Instructions

swoppster



Cover material

Microfibre

- Optimum care is ensured by using just water and pH neutral soapsuds. Stains containing oil and fat should be treated beforehand with ethyl alcohol.
- Rinse with clear water after each cleaning treatment. Never use chlorinated detergents.
- Only dampen the seat and never make it completely wet, otherwise the cushioning under the fabric might be damaged. Therefore use only very small amounts of water and detergent.
- Avoid marks by cleaning from the edge of the seat to the middle.

Cleaning of the foot ring

Clean the foot ring and guard using a damp cloth, if necessary with a little pH-neutral soap.

swoppster[®]
active swivel stool for children

